


# 52-5170 operating mode - 4 channel in, 4 channel out



Slotnumber = XLR Slot 1...14