52-5810M
RX2 Central Module, flush mount

+1

0 -60 -40 -30 -20 -10 0 +10

-1

PGM 1

Timer

0:00:00

Start | Stop | Reset

Fader

Main | Auto Mix | Aux Sends | Routing

Monitor

+1

0 -60 -40 -30 -20 -10 0 +10

-1

PGM 1

Guest 1

-20 dB

Talk

Guest 2

-20 dB

Talk

Guest 3

-20 dB

Talk

Pages

Aux Master | Auto mix | Routing | Meter

RX2

Home

Home | Snapshots | Settings | Monitor

Load Default

Layer B

Auto Off Air

Traffic

Talk 2

Talk 1

Talk Reply

7:51:13

-50 dB
CUE

-20 dB
CoMod

ON AIR

MIC ON

PHONE

TRAFFIC

EXT

TUNER

SEL

PGM 2

PGM 1

Monitor

Headphone

<< Control >>

DHD.audio

print layout scale 1:1 (full size)
paper size DIN A2