

XC3 Installation Instructions

Attention!
Due to heat generation,
ensure sufficient air
circulation.

I/O modules:
Above a 3-RU-block of I/O
modules, always leave 1 RU
empty.

Core / Concentrator:
always leave 1 RU above the
device empty.

Install device separately in one
19" adapter panel, always
leaving neighbouring slot empty.

Do not install any heat-dissipating
devices directly below.



Specifications and design are subject to change without notice.

The content of this document is for information only. The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does neither convey nor imply any license under patent- or other industrial or intellectual property rights.