


RS422 cable 52/XR - Pro-Bel ¹⁾

(not supplied by DHD)

controller Pro-Bel*
 *) pin using may differ
 from this recommendation!

controlled device
 52/XR
 52-5860 RS232/RS422 Extender



Pin	Function	Cable
1	chassis / GND	unused
2	RX-	RX- (pair 1)
3	TX+	TX+ (pair 2)
4	GND	cable shield (pair 2)
5	N/C	unused
6	GND	cable shield (pair 1)
7	RX+	RX+ (pair 1)
8	TX-	TX- (pair 2)
9	chassis	unused

Pin	Function	Cable
1	GND	unused
2	TX+	TX+ (pair 1)
3	RX-	RX- (pair 2)
4	chassis / GND	cable shield (pair 2)
5	GND	unused
6	chassis / GND	cable shield (pair 1)
7	TX-	TX- (pair 1)
8	RX+	RX+ (pair 2)
9	GND	unused

1) Pro-Bel protocol SW-P-02 converter license 52-8571 for 52/XR